




INSTALLATION GUIDE

PROMASTER VAN REAR DOOR PLATFORM - DRIVER'S SIDE

PM1103B



TOOLS REQUIRED (NOT INCLUDED)

+ AUTO PANEL REMOVAL TOOL	+ 7/32" ALLEN WRENCH
+ PAINTER'S TAPE	+ MARKER
+ MEASURING TAPE	+ T40 TORX
+ POWER DRILL	+ FLATHEAD SCREWDRIVER
+ 3/16" DRILL BIT	+ 4MM ALLEN WRENCH
+ 27/64" DRILL BIT	+ 5MM WRENCH/SOCKET
+ DEBUR TOOL	+ MEASURING TAPE
+ RUST PREVENTATIVE PAINT	
+ 9/16" WRENCH/SOCKET	
+ 5/32" ALLEN WRENCH	

INSTALL INFO

TIME TO INSTALL THIS PRODUCT: 1-2 HOURS

Additional help is suggested for a few of the install steps.

BEFORE YOU START

Please inspect the product and packaging upon delivery to ensure there are no issues and that all parts and hardware are accounted for.


Contact us ASAP if anything is missing at:
support@flatlinevanco.com

BEFORE YOU START

All Flatline Van Co products must be properly assembled and secured before attaching to your vehicle. Improper attachment could result in an automobile accident, and could cause serious bodily injury or death to you or to others involved. You are responsible for assembling and securing Flatline Van Co products to your vehicle, checking the mounting points and attachments prior to use, and regularly inspecting the products for wear and or damage. We always recommend you use a professional to install any aftermarket accessories to your vehicle. If you have no mechanical experience and are not thoroughly familiar with the installation procedures, you must have the product installed by a professional installer or other qualified persons. The responsibility is yours and must be taken seriously for everyone's safety.




PACKAGE CONTENTS




REAR DOOR PLATFORM

QTY: 1




BUSHING CAP

QTY: 1




TALL BUSHING

QTY: 1



SHORT BUSHING

QTY: 1



LIMIT STRAP ASSEMBLY

QTY: 1




BOTTLE OPENER

QTY: 1




UPPER HINGE BRACKET

QTY: 1




LICENSE PLATE BRACKET

QTY: 1




FRAME BRACE

QTY: 1



LOWER HINGE BRACKET

QTY: 1



UPPER HINGE BRACKET


QTY: 1



DRILL TEMPLATE


QTY: 1

HARDWARE




3/8-16 X 2.25 BUTTON
HEAD HEX DRIVE SCREW

QTY: 1



3/8-16 X 1 FLANGED HEX
HEAD SCREW

QTY: 6




3/8-16 X 1.25 SQUARE NECK
CARRIAGE BOLT

QTY: 4



1/4-20 X 0.75 FLANGED
BUTTON HEAD HEX DRIVE
SCREW

QTY: 2




3/8-16 NYLON LOCKNUT

QTY: 8



3/8 FLAT WASHER

QTY: 8



THREAD LOCKER

QTY: 1

INSTALL

STEP | 01 LAYOUT AND INSTALL PREP

1.1 Door Panel Removal: Remove the Lower Panel Trim (FIG 1) using plastic panel removal tools. Be gentle to avoid breaking the factory panel clips. If clips get stuck in the door, pop them out and slide them back into place on the trim panel.

NOTE- You may have any number of different door configurations- stock full trim, stock half trim, stock panel (Pictured FIG 1), upholstered wood, etc. Each require their own removal method.

TOOLS REQUIRED FOR THIS STEP: + AUTO PANEL REMOVAL TOOL



FIG 1




FIG 2




FIG 3

STEP | 02 DRILL FOR THIRD MOUNT

2.1 Marking Front Drill Location: Use the **Front Drill Template** to mark the outside of the rear driver door. The arrow should align with the **Right Side Of The Door** as shown in **FIG 4+5**.

NOTE - The template aligns to the contours of the van body's sheet metal and not the plastic trim of the license plate cover. Be sure to keep the template tight against the van body.

2.2 Drill Front-Facing Third Mount: Drill out your mark with a **Pilot Bit** (3/16" sized or similar) as shown in **FIG 6**, then enlarge it with a **27/64" Drill Bit** (**FIG 7**).

TOOLS REQUIRED FOR THIS STEP: + MARKER
+ POWER DRILL
+ 3/16" DRILL BIT
+ 27/64" DRILL BIT



FIG 4




FIG 5



FIG 6



FIG 7

STEP | 03 PREP FOR PLATFORM INSTALL

3.1 Paint Raw Edges: Deburr and paint the exposed edges for rust prevention (FIG 8+9)

3.2 Side Drill Template: Drill out a clearance hole for the **License Plate Relocation Bracket Wiring** using a **1/4"** or similar sized Drill Bit (FIG 10+11).

NOTE - Take care not to drill through the plastic housing that holds the license plate light in place.

TOOLS REQUIRED FOR THIS STEP:

- PAINTER'S TAPE
- RUST PREVENTATIVE PAINT
- POWER DRILL
- 1/4" DRILL BIT



FIG 8



FIG 9




FIG 10



FIG 11

STEP | 04 ASSEMBLE PLATFORM

4.1 Attach License Plate Relocation Bracket: Attach the License Plate Relocation Bracket to the Platform Frame using: **(2) 3/8-16 X 1.25 Carriage Bolts, Flat Washers and Nylon Locknuts** in the threaded locations shown in FIG 12+13

TOOLS REQUIRED FOR THIS STEP: + 9/16" WRENCH/SOCKET



FIG 12




FIG 13

STEP | 05 INSTALL VAN MOUNTS

5.1 Bottom Hinge Alignment Marks: Begin by marking alignment points at the bottom hinge of the driver-side door (FIG 14).

5.2 Release Bottom Hinge: Remove the three factory bolts of the lower hinge using a **T40 Torx** (FIG 15).

NOTE - *Be very careful not to strip the head of the bolts. Do not use power tools! Very easy to cross thread!!*

5.3 Position D2 Hinge Bracket: Support the door while swinging the hinge back to slide the **D2 Hinge Bracket** over it (FIG 16).

5.4 Secure D2 Hinge Bracket Reinstall the factory bolts snugly, then check clearances by slowly closing the door before tightening the bolts (FIG 17).

PRO-TIP: *Use a punch or screwdriver inside one of the threaded holes to keep the door aligned while you thread them in to avoid cross-threading.*

5.5 Repeat for D1 Hinge Bracket: Repeat the process for the upper hinge with the **D1 Hinge Bracket**. Ensure the door is supported to prevent twisting during hinge removal. After installing the **D1 Hinge Bracket**, test door function to ensure there is no contact with the van's body during operation.

TOOLS REQUIRED FOR THIS STEP:

- + T40 TORX
- + MARKER
- + SCREWDRIVER




FIG 14



FIG 15



FIG 16



FIG 17

STEP | 05 INSTALL VAN MOUNTS

5.6 Third Mount: Install the Third Mount to the drilled hole using a **3/8" Carriage Bolt, Bungee Bracket, 3/8" Flat Washer and Nylon Locknut** (FIG 18-21).

NOTE - Make sure that the **Bungee Bracket** is in the orientation as shown in FIG 21.

TOOLS REQUIRED FOR THIS STEP: + 9/16" WRENCH/SOCKET




FIG 18



FIG 19




FIG 20



FIG 21

STEP | 06 INSTALL PLATFORM

6.1 Hinge Mounts: With assistance, raise the Platform up to the door and insert **(2ea)** **3/8" Flanged Hex Head Screws** through the Upper **(FIG 22)** and Lower **(FIG 23)** Hinge Brackets. Loosely thread on **(2ea)** **3/8" Flat Washers and Nylon Locknuts**.

NOTE - Use extreme caution around factory rear windows while mounting Platform into position.



NOTE - Make sure that the "fins" of the **Platform** are on the inside of the **Hinge Brackets** as shown in **FIG 22 and 23**.

6.2 Third Mount: Insert the **Bushing Assembly** through the **Third Mount Bracket Hole** to center the Platform and secure using a **3/8" Flat Washer and Nylon Locknut**. **(FIG 24)**.

6.3 Lower Frame Brace: Use a **9/16" Wrench and Socket** to attach the lower frame brace tightly to the door using **(2ea)** **3/8" Flanged Hex Head Screws** and **(2ea)** **3/8" Flat Washers and Nylon Locknuts** **(FIG 23)**.

6.4 Checking Clearance: Ensure the third mount is secure, then operate the door to check for interference with mount brackets. If everything is lining up, tighten down all fasteners on the hinge mounts.

TOOLS REQUIRED FOR THIS STEP: + **9/16" WRENCH/SOCKET**
+ **7/32" ALLEN WRENCH**



STEP | 07 INSTALL LIMIT STRAP

7.1 Remove Factory Cap and Sticker Covers: Use a flathead screwdriver to remove the factory plastic cap along the inside of the door (FIG 25) and the stickers that cover the threaded holes of the van body (FIG 26).

7.2 Layout Limit Strap Components: Notice the components of the Limit Strap Assembly in FIG 27. You will first need the Limit Strap Bracket in the next step.

TOOLS REQUIRED FOR THIS STEP:

- + FLATHEAD SCREWDRIVER
- + 4MM ALLEN WRENCH
- + 5MM WRENCH/SOCKET



FIG 25



FIG 26




FIG 27

STEP | 07 INSTALL LIMIT STRAP

7.3 Attach Limit Strap to Bracket: Attach the Limit Strap Webbing to the Limit Strap Bracket using the longest M6 Socket Head Screw, Flat Washer and Nylon Locknut (if it isn't attached already).

NOTE - Note the middle loop of the webbing is facing inward for bungee.

7.4 Install Limit Strap Bracket: Install the Limit Strap Bracket to the threaded locations on the inside of the door jam using the supplied M6 Socket Head Screws (FIG 28).

7.5 Install Webbing Guide: Attach Limit Strap to the Webbing Guide (if it isn't already) and install to the van in the location shown in FIG 32 using (2ea) M6 Socket Head Screws, Flat Washers and Nylon Locknuts (FIG 30).

TOOLS REQUIRED FOR THIS STEP: + 4MM ALLEN WRENCH
+ 5MM WRENCH/SOCKET



FIG 28



FIG 29



FIG 30




FIG 31

TOOLS REQUIRED FOR THIS STEP: + MEASURING TAPE

STEP | 07 INSTALL LIMIT STRAP

7.6 Layout Limit Strap Retraction Bungee: Run the Limit Strap Retraction Bungee through the sewn loop in the middle of the Limit Strap and tie off using an **Figure 8 Knot** (or similar) at about 14" long (FIG 32).

7.7 Tie to Bungee Bracket: Run the Limit Strap Retraction Bungee through the **Bungee Bracket**, pull until tight and tie off using a standard **Overhand Knot** (FIG 33).



FIG 32



FIG 33






FIG 34

STEP | 09 FOOT PEGS & BOTTLE OPENER

9.1 Bottle Opener: Attach the **Bottle Opener** to the **Third Mount Bracket** using **(2) 1/4-20 x 0.75 Flanged Button Head Screws** (FIG 35+36).

TOOLS REQUIRED FOR THIS STEP: + LOCTITE
+ 5/32" ALLEN WRENCH



STEP | 10 LICENSE PLATE LIGHT WIRING

10.1 License Plate Relocation Wiring: Using your preferred method, splice in the **License Plate Light**. Be sure to wire the new light in *parallel* to your **Factory License Plate Light Harness**. (White to Red and Black to Black)

NOTE - We recommend sealing around the drill hole with silicone to prevent debris and moisture from entering the door cavity (**FIG 37**).

NOTE - This kit features an LED license plate light. Due to LED lights having a lower resistance compared to factory incandescent bulbs, some vehicles may display a "bulb out" warning on the dash. Installing an appropriate load resistor (not included) typically resolves this.

TOOLS REQUIRED FOR THIS STEP:



FIG 37




FIG 38

GET OUT AND EXPLORE!

+ LEAVE US A REVIEW

Happy with your new FVC product? We would love to hear (and see) from you! Head to the product page and click "Leave Review." Add a short review and upload a few photos to be showcased on the product page.

+ SHARE YOUR PICS

We love seeing how our customers use their FVC products and following along with your adventures. Tag us in your photos with: @flatlinevanco or send them to us via email. We love posting customer pictures in our feed!

+ NEED ANY HELP?

If you are having any issues with your product, please reach out, and we will make it right. FVC is a company of van and outdoor enthusiasts that design and use our own products, so we want you to be as stoked on your new parts as we are!




@FLATLINEVANCO



INSTALLATION GUIDE

PROMASTER VAN REAR DOOR PLATFORM - PASSENGER'S SIDE

PM1104B



TOOLS REQUIRED (NOT INCLUDED)

+ AUTO PANEL REMOVAL TOOL	+	5/32" ALLEN WRENCH
+ PAINTER'S TAPE	+	7/32" ALLEN WRENCH
+ MEASURING TAPE	+	MARKER
+ POWER DRILL	+	T40 TORX
+ 3/16" DRILL BIT	+	FLATHEAD SCREWDRIVER
+ 27/64" DRILL BIT	+	4MM ALLEN WRENCH
+ DEBUR TOOL	+	5MM WRENCH/SOCKET
+ RUST PREVENTATIVE PAINT	+	MEASURING TAPE
+ 9/16" WRENCH/SOCKET		

INSTALL INFO

TIME TO INSTALL THIS PRODUCT: 1-2 HOURS

Additional help is suggested for a few of the install steps.

BEFORE YOU START

Please inspect the product and packaging upon delivery to ensure there are no issues and that all parts and hardware are accounted for.


Contact us ASAP if anything is missing at:
support@flatlinevanco.com

BEFORE YOU START

All Flatline Van Co products must be properly assembled and secured before attaching to your vehicle. Improper attachment could result in an automobile accident, and could cause serious bodily injury or death to you or to others involved. You are responsible for assembling and securing Flatline Van Co products to your vehicle, checking the mounting points and attachments prior to use, and regularly inspecting the products for wear and or damage. We always recommend you use a professional to install any aftermarket accessories to your vehicle. If you have no mechanical experience and are not thoroughly familiar with the installation procedures, you must have the product installed by a professional installer or other qualified persons. The responsibility is yours and must be taken seriously for everyone's safety.




PACKAGE CONTENTS



REAR DOOR PLATFORM

QTY: 1




LIMIT STRAP ASSEMBLY

QTY: 1




BOTTLE OPENER

QTY: 1




BOTTLE OPENER

QTY: 1



DRILL TEMPLATE

QTY: 1




FRAME BRACE

QTY: 1




LOWER HINGE BRACKET

QTY: 1




UPPER HINGE BRACKET

QTY: 1




BUSHING CAP

QTY: 1



TALL BUSHING


QTY: 1



SHORT BUSHING


QTY: 1

HARDWARE




3/8-16 X 2.25 BUTTON
HEAD HEX DRIVE SCREW

QTY: 1



3/8-16 X 1 FLANGED HEX
HEAD SCREW

QTY: 6




3/8-16 X 1.25 SQUARE NECK
CARRIAGE BOLT

QTY: 1



1/4-20 X 0.75 FLANGED
BUTTON HEAD HEX DRIVE
SCREW

QTY: 2




3/8-16 NYLON LOCKNUT

QTY: 8



3/8 FLAT WASHER

QTY: 8



THREAD LOCKER

QTY: 1




INSTALL

STEP | 01 LAYOUT AND INSTALL PREP

1.1 Door Panel Removal: Remove the Lower Panel Trim (FIG 1) using plastic panel removal tools. Be gentle to avoid breaking the factory panel clips. If clips get stuck in the door, pop them out and slide them back into place on the trim panel.

NOTE- You may have any number of different door configurations- stock full trim, stock half trim, stock panel (Pictured FIG 1), upholstered wood, etc. Each require their own removal method.

TOOLS REQUIRED FOR THIS STEP: + AUTO PANEL REMOVAL TOOL



STEP | 02 DRILL FOR THIRD MOUNT

2.1 Marking Front Drill Location: Use the **Front Drill Template** to mark the outside of the rear passenger door. The arrow should align with the **Left Side Of The Door** and **Left Side Of The Grab Handle** as shown in FIG 4+5.



NOTE - *The template aligns to the contours of the van body's sheet metal and not the plastic trim of the Grab Handle. Be sure to keep the template tight against the van body.*

2.2 Drill Front-Facing Third Mount: Drill out your mark with a **Pilot Bit** (3/16" sized or similar), then enlarge it with a **27/64"** **Drill Bit**.

2.3 Paint Raw Edges: Deburr and paint the exposed edges for rust prevention.

TOOLS REQUIRED FOR THIS STEP:

+	MARKER	+	27/64" DRILL BIT
+	POWER DRILL	+	METAL FILE
+	3/16" DRILL BIT	+	RUST PREVENTATIVE PAINT



STEP | 03 INSTALL VAN MOUNTS

3.1 Bottom Hinge Alignment Marks: Begin by marking alignment points at the bottom hinge of the passenger-side door (FIG 6).

3.2 Release Bottom Hinge: Remove the three factory bolts of the lower hinge using a T40 Torx (FIG 7).

NOTE - Be very careful not to strip the head of the bolts. Do not use power tools! Very easy to cross thread!!

3.3 Position P2 Hinge Bracket: Support the door while swinging the hinge back to slide the P2 Hinge Bracket over it (FIG 8).

3.4 Secure P2 Hinge Bracket Reinstall the factory bolts snugly, then check clearances by slowly closing the door before tightening the bolts (FIG 9).

PRO-TIP: Use a punch or screwdriver inside one of the threaded holes to keep the door aligned while you thread them in to avoid cross-threading.

3.5 Repeat for P1 Hinge Bracket: Repeat the process for the upper hinge with the P1 Hinge Bracket. Ensure the door is supported to prevent twisting during hinge removal. After installing the P1 Hinge Bracket, test door function to ensure there is no contact with the van's body during operation.

TOOLS REQUIRED FOR THIS STEP:

- + T40 TORX
- + MARKER
- + SCREWDRIVER



FIG 6



FIG 7



FIG 8



FIG 9

STEP | 03 INSTALL VAN MOUNTS

3.6 Third Mount: Install the **Third Mount** to the drilled hole using a **3/8" Carriage Bolt, Bungee Bracket, 3/8" Flat Washer and Nylon Locknut** (FIG 10-12).

NOTE - Make sure that the **Bungee Bracket** is in the orientation as shown in FIG 12.

TOOLS REQUIRED FOR THIS STEP: + 9/16" WRENCH/SOCKET




FIG 10




FIG 11



FIG 12

TOOLS REQUIRED FOR THIS STEP: + 9/16" WRENCH/SOCKET
+ 7/32" ALLEN WRENCH

STEP | 04 INSTALL PLATFORM

4.1 Hinge Mounts: With assistance, raise the Platform up to the door and insert (2ea) 3/8" Flanged Hex Head Screws through the Upper (FIG 13) and Lower (FIG 14) Hinge Brackets. Loosely thread on (2ea) 3/8" Flat Washers and Nylon Locknuts.



NOTE - Use extreme caution around factory rear windows while mounting Platform into position.

NOTE - Make sure that the "fins" of the **Platform** are on the inside of the **Hinge Brackets** as shown in FIG 13 and 14.

4.2 Third Mount: Insert the **Bushing Assembly** through the **Third Mount Bracket Hole** to center the Platform and secure using a 3/8" Flat Washer and Nylon Locknut. (FIG 15).

4.3 Lower Frame Brace: Use a 9/16" Wrench and Socket to attach the lower frame brace tightly to the door using (2ea) 3/8" Flanged Hex Head Screws and (2ea) 3/8" Flat Washers and Nylon Locknuts (FIG 14).

4.4 Checking Clearance: Ensure the third mount is secure, then operate the door to check for interference with mount brackets. If everything is lining up, tighten down all fasteners on the hinge mounts.



STEP | 05 INSTALL LIMIT STRAP

5.1 Remove Factory Cap and Sticker Covers: Use a flathead screwdriver to remove the factory plastic cap along the inside of the door (FIG 16) and the stickers that cover the threaded holes of the van body (FIG 17).

5.2 Layout Limit Strap Components: Notice the components of the Limit Strap Assembly in FIG . You will first need the Limit Strap Bracket in the next step.

TOOLS REQUIRED FOR THIS STEP:

- + FLATHEAD SCREWDRIVER
- + 4MM ALLEN WRENCH
- + 5MM WRENCH/SOCKET



FIG 16




FIG 17




FIG 18

STEP | 05 INSTALL LIMIT STRAP

5.3 Attach Limit Strap to Bracket: Attach the Limit Strap Webbing to the Limit Strap Bracket using the longest M6 Socket Head Screw, Flat Washer and Nylon Locknut (if it isn't attached already).

NOTE - Note the middle loop of the webbing is facing inward for bungee.

5.4 Install Limit Strap Bracket: Install the Limit Strap Bracket to the threaded locations on the inside of the door jam using the supplied M6 Socket Head Screws (FIG 19).

5.5 Install Webbing Guide: Attach Limit Strap to the Webbing Guide (if it isn't already) and install to the van in the location shown in FIG 20 using (2ea) M6 Socket Head Screws, Flat Washers and Nylon Locknuts (FIG 21).

TOOLS REQUIRED FOR THIS STEP: + 4MM ALLEN WRENCH
+ 5MM WRENCH/SOCKET




FIG 19




FIG 20



FIG 21




FIG 22

TOOLS REQUIRED FOR THIS STEP: + MEASURING TAPE

STEP | 05 INSTALL LIMIT STRAP

5.6 Layout Limit Strap Retraction Bungee: Run the **Limit Strap Retraction Bungee** through the sewn loop in the middle of the **Limit Strap** and tie off using an **Figure 8 Knot** (or similar) at about 14" long (FIG 23).

5.7 Tie to Bungee Bracket: Run the **Limit Strap Retraction Bungee** through the **Bungee Bracket**, pull until tight and tie off using a standard **Overhand Knot** (FIG 24).



FIG 23




FIG 24




FIG 25

STEP | 06 FOOT PEGS & BOTTLE OPENER

6.1 Bottle Opener: Attach the **Bottle Opener** to the **Third Mount Bracket** using **(2) 1/4-20 x 0.75 Flanged Button Head Screws** (FIG 26+27).

TOOLS REQUIRED FOR THIS STEP: + LOCTITE
+ 5/32" ALLEN WRENCH




FIG 26




FIG 27

GET OUT AND EXPLORE!

+ LEAVE US A REVIEW

Happy with your new FVC product? We would love to hear (and see) from you! Head to the product page and click "Leave Review." Add a short review and upload a few photos to be showcased on the product page.

+ SHARE YOUR PICS

We love seeing how our customers use their FVC products and following along with your adventures. Tag us in your photos with: @flatlinevanco or send them to us via email. We love posting customer pictures in our feed!

+ NEED ANY HELP?

If you are having any issues with your product, please reach out, and we will make it right. FVC is a company of van and outdoor enthusiasts that design and use our own products, so we want you to be as stoked on your new parts as we are!



@FLATLINEVANCO